

INSTALLATION GUIDE

ID-Sx7x/yyy Self-Mounting Photoluminescent Signs
for Marine, Oil & Gas and Industrial Applications



RAILING / POLE

PRE-INSTALLATION



IDIGO Signage Plate



Scissors



Rubber Sheet



Installation Tool



Garbage Bags



Cable Ties



Grip Gloves



Plate Accessories



M6 Bolt Spanner



Marker Pen

INSTALLATION

- 1** Determine location of sign (refer to Fire & Safety Control Plan)



Ensure the railing/pole surface is clean to obtain smooth and straight mounting

- 2** Assemble the signage accessories accordingly



start with the M6 bolt, flat washer, aluminium backingboard (with safety sign), serrated washer, bracket and nutlock. Tighten using spanner

- 3** Measure the railing circumference and cut the rubber based on the railing size.



Join the rubber using cellophane tape. Ensure there is no gap visible between the rubber

- 4** Measure the distance between the bracket on the railing and mark using marker pen



Repeat step 3-4 for second rubber sheet

- 5** Slot cable tie through the bracket hole



Join the cable-tie. Make sure the sign is parallel to railing while tightening

- 6** Snip off excess lengths using installation tool



GENERAL

- Wear safety gloves during installation.
- Please collect all trash and dispose accordingly

COMPLETE!

